

Plastic Roost Deflector Part Number 51-220 thru 229 will be required. If you haven't already, visit enduroeng.com to select your color.

1. Choose between the Clutch side and the Brake Side to start with. It does not matter which you start with the process is the same for both sides.
2. Using a T-25 Torx wrench on the lever pivot bolt and 10mm combination wrench on the bottom nut. Remove the lever pivot bolt. (FIG 1)
3. Using an 8mm T-Handle or socket. Remove the master cylinder mounting bolt. (FIG 2)
4. Create a hole about the size of pivot bolt in the rubber cover on the master cylinder over the Braketech logo to line up with the pivot bolt hole in the perch. (FIG 3)
5. Take the correct side moto mount. The Part number on the aluminum arm will end in an L for left or R for right.
6. Take the provided M6x30 bolt and slide it through the moto arm, then through the provided aluminum spacer, then into the master cylinder perch. Leave this bolt finger tight for now. (FIG 4)
7. Take the provided lever pivot bolt and slide the rubber sleeve over the bolt. Apply a small amount of waterproof grease to the pivot bolt. (FIG 5)
8. Slide the pivot bolt through the aluminum moto mount arm, then through the lever. Use the nut that you removed in step 2 to thread on the pivot bolt on the underside of the perch. (FIG 6)
9. Using an 8mm T-Handle or socket, tighten the master cylinder perch mounting bolt with the levers at the desired position.
10. Using a 4mm allen wrench and a 10mm combination wrench, tighten the lever pivot bolt. (FIG 6)
11. Repeat Steps 2-10 on opposite side.
11. Using the provided screws, install the Enduro Engineering Plastic roost deflectors.
12. Have fun and enjoy your next ride!



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5

FIG 6



WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

ALUMINUM MOTO MOUNT INSTALLATION INSTRUCTIONS PART NUMBER 53-2122

Quality Off-Road Motorcycle Products

enduroeng.com/517.393.2421/info@enduroeng.com