EE Radiator Guards Installation Instructions

















WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. RJRF.Sec.randt.warninganddisclaimer.5 2 08

Note: Installation of this product requires the use of Enduro Engineering 11-150 radiator braces.

- Remove seat, gas tank, radiator shrouds, and plastic louvers
- Drain radiator coolant, by removing the radiator cap and then the coolant drain plug on the side of the water pump (Fig 1)
- Reinstall coolant drain plug
- Loosen the hose clamps on the top and bottom of the radiators, then pull the hoses off the radiators (Fig 2)
- Remove the 4 or 6 bolts holding the radiators to the frame
- Using the supplied 6x16mm button head bolts attach one side of the radiator guard to the corresponding (R or L) big piece of the 11-150 Radiator Brace. (Fig. 3)
- Slide this assembly over the radiator as shown. (Fig. 4)
- Connect the corresponding small radiator brace piece to the guard assembly using the supplied 6x16mm and 6x8mm button head bolts. (Fig. 5)
- Reconnect the radiator and Brace/Guard assembly to the frame using the supplied 6x30mm hex head bolts and 22mm washers. (Fig. 6)
- Repeat steps 2-4 on the opposite side of the bike.
- Connect all radiator hoses and tighten clamps.

- Add coolant.
- Attach the gas tank and shrouds.
- Attach the provided 6mm clip nut on the lower radiator shroud mount. (Fig. 7)
- Use the provided 6x25mm hex head bolts and the nylon spacer at the lower shroud mount (spacer between the shroud and radiator). (Fig. 8)
- Reinstall the seat.
- Ride safe and have fun!



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Radiator Guards Installation

Part# 12-150