

1. Using an 8mm T-Handle or socket, remove the 4 mounting bolts for the OEM Skid plate. There is two towards the front of the frame near the top of the skid plate (FIG 1), and two bolt under each footpeg (FIG 2). Once the bolts are removed pull the OEM Skid Plate downward to remove.
  2. Take the provided bracket for the Enduro Engineering Skidplate and mount it to the front of the skid plate with the Enduro Engineering Sticker reading right side up. Use two of the provided M6x20 bolts to thread through the rubber mounted holes on the front of the skidplate. (FIG 3) Tighten using an 8mm T-Handle or Socket.
- IF YOU ARE USING AN ENDURO ENGINEERING SKID PLATE MOUNTED LINKAGE GUARD NOW WOULD BE THE TIME TO INSTALL.**
3. Hold the Enduro Engineering Skid Plate up to the frame and line up the same front mounting holes as the OEM skid plate used with the bracket of the EE Skid Plate. Using 2 of the provided M6x25 bolts thread them through the frame and into the bracket of the EE Skidplate. (FIG 4) Leave them loose for now.
  4. Thread the remaining provided M6x25 bolts through the rear rubber mounted mounting holes on the EE skid plate on each side underneath the footpegs. (FIG 5)
  5. Starting with the rear mounting bolts, tighten each side using an 8mm T-Handle or Socket. (FIG 6)
  6. Tighten the front two mounting bolts using an 8mm T-Handle or socket. (FIG 7)
  7. Have Fun and enjoy your next ride.



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5



FIG 6



FIG 7

## WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

## SKID PLATE INSTALLATION INSTRUCTIONS PART NUMBER 24-1223



[enduroeng.com//517.393.2421//info@enduroeng.com](http://enduroeng.com//517.393.2421//info@enduroeng.com)