

EE Bar Riser Instructions

- 1 Using a 10mm socket remove the 2 upper handlebar clamps (Fig 1)
- 2 Remove the handlebars from the lower handlebar mount and rest them in front of the number plate.
- 3 Using a T-45 Torx bit (from your KTM tool kit) remove the 2, 10mm bolts that fasten your lower handlebar clamp to your top triple clamp. (Fig 2)
- 4 Using the chart below select the correct length supplied bolts for the height bar riser that you choose to install.
5mm bar riser requires the 40mm long bolts
10mm bar riser requires the 45mm long bolts
15mm bar riser requires the 50mm long bolts
20mm bar riser (5mm & 15mm stacked) requires the 55mm long bolts

NOTE: We do not recommend using any combination higher than 20mm.

- 6 Apply a small amount of liquid thread lock to the threads of the bolts that you are going to install.
- 7 Install the bolts through the lower handlebar mount and through the appropriate bar risers from the chart above (with the raised center of the bar riser pointed up) and thread them into the threaded sleeves that are installed in the top triple clamp. (Fig 3)
- 8 Using the supplied 8mm Allen wrench, tighten both of the lower handlebar clamp bolts. (Fig 4) **NOTE:** You may need to hold the bottom of the threaded sleeve with a 17mm wrench if the threaded insert rotates when tightening.
- 9 Center your handlebars in the lower handlebar mount and reinstall the 2 top handlebar clamps. Using a 10mm socket torque the 4 top handlebar clamp bolts to the manufactures specifications.



FIG 1



FIG 2




FIG 3



FIG 4

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer. 5 2 08



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Bar Riser Instructions

Part# 23-016