

1. Using a 10mm T-Handle or Socket, Remove the 4 handlebar top clamp bolts. Set to the side, you will reuse these. (FIG 1)
2. Pull handlebars off and let them hang off of the front of the bike.
3. Using a 8mm Allen wrench, remove the OEM Handlebar bottom clamp bolts. You will not reuse these. (FIG 2)
4. Decide your desired Height. You have an option to raise 5mm, 10mm, 15mm, or 20mm.
  - To Raise 5mm: use the Riser labeled 5mm. You will have one for both sides. Use provided 40mm bolt.
  - To Raise 10mm: use the Riser labeled 10mm. You will have one for both sides. Use provided 50mm bolt.
  - To Raise 15mm: use the Riser labeled 15mm. You will have one for both sides. Use provided 60mm bolt.
  - To Raise 20mm: use 1 of the 5mm Risers along with a 15mm Riser on each side. Use Provided 60mm bolt.
5. Decide if you will use the front or rear mounting hole on the triple clamp. After applying lock tight to the bolts, take your provided bolt and insert it through the lower handlebar clamp and through your handlebar riser insert holes. Line the bolt up to your desired mounting hole on the triple clamp. There is a peg on the Riser that will fall into the unused mounting hole on the triple clamp. Start bolt by hand. (FIG 3)
6. Using a 7mm Allen wrench, tighten the mounting bolt to factory spec. (FIG 2)
7. Repeat on opposite handlebar mount.
8. Replace your handlebars on the handlebar mount.
9. Using the top clamp and bolt you removed in step 1, replace the top clamps.
10. Using an 10mm T-Handle or Socket, tighten handlebar top clamp bolts to factory spec.
11. Have fun and enjoy your next ride.



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5

## WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

PART # 23-9020

## Handlebar Riser Installation Instructions

Quality Off-Road Motorcycle Products



[enduroeng.com//517.393.2421//info@enduroeng.com](http://enduroeng.com//517.393.2421//info@enduroeng.com)