

# Honda CRF250R Skid Plate Installation Instructions

**1** Using an 8mm socket or T-handle, remove the 2 bolts that hold on the stock plastic case guard on the left side of the bike. (Fig 1)

**2** Install the rear mount of the skid plate with the hook of the bracket up over the center cross tube of the frame, hooking on the frame cross piece between the shock linkage arms. (Fig 2)

## WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF:Sec.randt.warninganddisclaimer. 5 2 08




**3** The threaded part of the rear mount should end up parallel with the lower frame rails. (Fig 3)

**4** Hold the skid plate up to the bottom of the frame and start (but don't tighten) the two supplied 8x25mm flat head bolts into the rear mounting bracket. (Fig 4)

**5** Slide the front mounting bracket between the engine cases and the front frame rails with the cut-outs facing forward. (Fig 5)

**6** Install the two supplied 8x40mm flat head bolts through the skid plate and into the front mounting bracket. While pushing up on the skid plate tighten the front mounting bolts with a 5mm Allen wrench and then tighten the rear mounting bolts. (Fig 6)



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Honda CRF250R Skid Plate  
Part# 24-672, 24-673, 24-674