- 1. Remove the seat (FIG 1)
- 2. Using a 4mm Allen Wrench, remove the 5 allen head bolts from the shroud. (FIG 2)
- 3. Using an 8mm T handle or Socket, remove the bolt holding the shroud to the radiator. (FIG 3)
- 4. Remove the OEM Radiator Louver by pressing the two out tabs inward and forward. (FIG 4)
- 5. Using a closed end 8mm Wrench, remove the two bolts holding the radiator to the frame of the motorcycle. (FIG 5)

6. Take one of the brackets labeled 12-9013-02 and mount it to the bolt holes from step 5 using 2 of the provided M6X25 bolts. (FIG 6) Make sure the stamped part number is facing the frame.

7. Depending on what side you started with, take either the 12-9013-03L or 12-9013-03R. (L for left, R for right) and mount it to the outside of the radiator using 2 of the provided M6x16 bolts. Tighten using a closed end 8mm Wrench (FIG 7) Make sure the stamped part number is facing inward towards the frame so front guard mounting holes are facing forward.

8. Take either the 12-9013-01L or 12-9013-01R, depending on what side you are working on, and line it up to both brackets you mounted in steps 6 and 7. There should be 4 mounting holes on the outside edge, and 3 mounting holes on the inside, or frame side edge. Using 7 of the provided 5x16 Socket head bolts, mount the front guard to the mounting brackets. Tighten using a 4mm Allen Wrench. (FIG 8)

9. Replace shroud using the same bolts you removed in steps 2 and 3.

- 10. Repeat steps 2 through 9 on opposite side.
- 11. Replace Seat.
- 12. Have fun and enjoy your next ride!





WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician, Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after marker parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose

PART NUMBER: 12-9013 Sherco Radiator Guard Installation Instructions



enduroeng.com//517.393.2421//info@enduroeng.com