Skid Plate Installation Instructions

- 1 Remove the stock plastic skid plate.
- Position the EE skid plate so that the front mounting holes in the skid plate align with the factory mounting tabs on the frame. Using the two supplied M6x20 flat head bolts, partially thread them in to the factory mounting tabs. (Fig 1)
- *NOTE: Installation may be easier with the motorcycle laying on its side.
- Working from the right side of the motorcycle with the skid plate hanging low in the back, position the rear clamp (part # 016-02) on to the top of the rear frame rail. Hold the clamp in position by reaching over the rear shock linkage to hold the clamp onto the frame. While holding the clamp in position, push the skid plate up against the frame. Then insert the supplied M8x25 flat head bolts into the rear mounting holes of the EE skid plate and thread them in finger tight. (Fig 2 and 3)







- 4 Using a 4mm L bend Allen wrench tighten the front two mounting bolts. (Fig 4)
- Use a 5mm Allen wrench to tighten the two rear mounting bolts. (Fig 5)

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EITs customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues, and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. RJRE.Sec.randt.warninganddisclaimer.5 2 08



FIG 2



Add EE Linkage Guard Part Number: 31-017



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Skid Plate Installation

Part# 24-7018