## **EE Installation Instructions**



- 1 Using an 8mm t-handle or socket remove the right side panel. (Fig 1)
- 2 Pull the left side panel off. (Fig 2)
- 3 Using an 8mm t-handle or socket remove the seat bolt. (Fig 3)
- 4 Using an 8mm t-handle or socket remove the gas tank bolt. (Fig 4)
- 4a Note: Turn off the fuel valve and disconnect the gas line. (Fig 5)
- 5 Using an 8mm t-handle or socket remove the shroud bolts and remove the tank. (Fig 6)
- 6 Using a 4mm allen wrench drain the coolant. (Fig 7)
- 7 With no coolant in the bike remove all of the radiator hoses from the radiators.
- 8 Push the plastic radiator louvers towards the center of the bike to remove them from the radiators. (Fig 8)
- 9 Using an 8 mm t-handle or socket remove the 4 radiator mounting bolts.
- **10** Connect support rods using M6x16 button head bolts.

## WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer. 5 2 08

- **10a** Install one <u>STRAIGHT</u> rod at the bottom of the radiator brace labeled R1.
- 10b Install one offset rod at the top of the same piece.
- **10c** NOTE: Notice the offset orientation, be sure the rod is offset towards the front of the bike. See (Fig 9)
- 11 Slide the brace over the radiator and onto the mounting posts on the frame.
- 12 Using an 8mm t-handle or socket and the supplied 6x16 hex head bolts, 6x22 washers followed by the supplied washers, mount the radiators to the frame. (Fig 10)
- 13 Using the supplied 6x16 button head bolts connect R2 to the rods, and use the 6x8 button head bolts to connect R1 and R2 on the back side. (Fig 11)
- 14 Repeat steps 10-13 for L1 and L2. (Fig 12 shows left side orientation)
- **15** Reinstall all of the radiator hoses and tighten the clamps.
- 16 Install the plastic louvers.
- 17 Install the gas tank, replenish the coolant.
- 18 Install the supplied rubber straps through the mounting holes in the shrouds (Fig 13), pull them across the radiator louvers and hook them on the inside radiator brace tab. (Fig 14)
- **19** Reinstall the seat, as well as the side panels.



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS EE Installation Instructions

Part# 11-7018