Enduro Engineering Installation Instructions


Using a 4mm allen wrench remove the OEM plastic skid plate along with the hardware.

1a NOTE: none of this hardware will need to be used

Place the provided M8 clip nut on the frame tab as shown (fig. 1).

Position the "24-300-03" strap between the frame rails and the engine as shown (fig. 2).

4 Using the provided M8x35mm flat head bolt, secure the back side of the skid plate to the clip nut installed in step 2 (**fig. 3**).





WARNING AND DISCLAIMER


All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and properly damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/rc consequential damages, properly damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI anising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI, must be brought in the Michigan and that Michigan law shall apply on all issues, and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. RJRF.Sec.randt. ^{4a} NOTE: only finger tighten at this time

⁵ Using the provided M8x45mm flat head bolts, connect the front portion of the skid plate to the strap installed in step 3 (fig. 4).

- ⁶ Tighten all three mounting bolts evenly.
- 7 Have fun and ride safe!

Add EE Linkage Guard Part Number: 31-017







QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS Enduro Engineering Installation Part# 24-900