## **EE Front Disc Guard Installation Instructions**











## WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchases. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose, R.JRE.Sec.randt.warninganddisclaimer. 5 2 08

- Using a 22mm socket, remove the front axle bolt. (Fig. 1)
- Using a 10mm t-handle or socket remove the lower brake caliper mounting bolt. (Fig. 2)
- Mount the disc guard to the fork leg using the original front axle bolt but only finger tight at this time. (Fig 3)
- Apply some thread locking agent to the threads of the supplied 8 x 45mm hex head flange bolt that will replace the original caliper bolt you removed in step 2. (Fig 4) With a 10mm T-handle or socket lightly tighten the 8 x 45mm bolt into the lower brake caliper mounting hole. (Fig 5)
- Using a torque wrench with a 22mm socket, torque the front axle screw to the manufacturer's torque specifications.
- Using a torque wrench with a 10mm socket, torque both the lower and upper brake caliper mounting bolt to the manufacturer's torque specifications.



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Front Disc Guard

Part# 32-154, 32-155, 32-5014