

## EE Installation Instructions



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5



FIG 6

### WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.  
R.JRF.Sec.randt.warninganddisclaimer. 5 2 08

**1** Using a 8mm socket remove the hex head bolt securing the air box and rear fender to the right side of the sub frame shown in **Fig 1**. You will not re-use this bolt. You will have to re-use the shoulder washer.

**2** With a T-45 Torx bit or 6mm Allen wrench (Depending on the year of your bike) remove the flat head bolt securing the right side of the sub frame to the motorcycle frame shown in **Fig 2**. You will not re-use this bolt.

**3** Position the exhaust guard on the side of the sub frame, over the side panel as shown in **Fig 3**.

**4** Apply a drop of thread lock to the supplied 8x25mm flat head sub frame bolt. Fasten the exhaust guard to the front of the sub frame and torque the bolt to manufactures recommended torque spec. **Fig 4**

**5** Apply a drop of thread lock to the supplied 6x25mm flat head sub frame bolt. Fasten the exhaust guard to the back of the sub frame and torque the bolt to manufactures recommend torque spec. **Fig 5**

**6** **Fig 6** shows the exhaust guard installed.

**Enduro Engineering**

QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Installation

Part# 40-062